



## Wall Clock Camera User Manual



- 1, DVR Power on/off switch is to control the spy camera power on or off.
- 2, USB for DVR is to connect PC and charging propose



To start recording first need move the power switch at on side, then press remote control button to send command to the antenna area to start recording, during recording press the button again then stop recording, the remote controller working effective range is 5 meters,  
When the DVR is recording, the LED will flicking(the led light can be see at USB port area),

when it stop back to standby status the LED is on with no flicking.

How to use it?

- 1, Move the power switch at on side,
- 2, Press remote controller button for three seconds to power on the device, the LED will turn on
- 3, When the LED is on means the DVR is ready to recording video, press the remote button again to start recording, then the LED will flicking means the device is recording.
- 4, To stop recording press the remote controller button again, the LED will not flicking, just on, it is means on standby status.
- 5, you also can press the record button to start recording, operate same as the remote.
- 6, when you are do not use the DVR system, please move the switch at off side.

How to Charging?

- 1, when the battery use out, you need charge it through the USB port.
- 2, you can connect it to PC's USB port via the USB cable, after few seconds will find a new USB driver, you need unload it, then will charger automatically.
- 3, Use the charger with the USB cable to charge from power source.

Play back

For the play, you just need connect it with PC's USB port via USB cable, the system will find a hardware disk automatically, then you can play or copy it.